

OPERATING INSTRUCTIONS FOR THE STREAMLIGHT PROTAC® 2.0 SERIES




IMPORTANT: FULLY CHARGE BATTERY BEFORE FIRST USE.

Thank you for selecting the **ProTac® 2.0** or **ProTac® 2.0 HP**, a truly remarkable light. As with any professional tool, reasonable care and maintenance of this product will provide years of dependable service. Please read this manual before using the ProTac®. It contains important safety and operating instructions.

SAVE THESE INSTRUCTIONS. This guide contains important safety and operating instructions for your ProTac®.

⚠ CAUTION STROBE MODE MAY CAUSE SEIZURES IN PERSONS WITH PHOTOSENSITIVE EPILEPSY.

⚠ WARNING  Fire and burn hazard. The ProTac® 2.0 series provide a powerful beam. When operated for more than a few seconds, it will get hot. Never leave your ProTac® with its face against any surface, including skin, while in operation. Transport or store the ProTac® in a way that minimizes the chance it can accidentally be turned on. The resultant heat build-up can cause a fire, burns or damage to the flashlight.

LED SAFETY

⚠ CAUTION LED RADIATION (RG-2). DO NOT STARE INTO BEAM. MAY BE HARMFUL TO EYES. PER IEC 62471 Ed 1.0:2006-07.

BATTERY SAFETY

⚠ CAUTION EXPLOSION RISK, BURN, AND FIRE HAZARD. DO NOT DISASSEMBLE, CRUSH, SHORT CIRCUIT, HEAT ABOVE 140°F (60°C), OR DISCARD IN FIRE. USE ONLY WITH THE SPECIFIED STREAMLIGHT PRODUCTS. KEEP AWAY FROM CHILDREN. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

⚠ WARNING RISK OF INJURY. THE USE OF SUBSTANDARD OR AFTERMARKET COMPONENTS, MODIFICATIONS TO THE ORIGINAL PARTS, OR USE OF THIS FLASHLIGHT WITH ANY INCOMPATIBLE PRODUCT MAY VOID WARRANTY AND COULD LEAD TO PRODUCT FAILURE OR PERSONAL INJURY.

CHARGING

NOTICE Charge battery before first use.

The ProTac® 2.0 series ship with a rechargeable SL-B50® Li-Ion battery. The SL-B50® battery is recyclable. At the end of its useful life, under various country and state laws, it may be illegal to dispose of this battery in the municipal solid waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal (In USA: RBRC).

The SL-B50® battery can be charged outside the light or while installed. The battery itself contains charge circuitry and indicators for charging. The battery may be left plugged into a USB-C cable continuously, there is no danger of overcharge.

To charge inside the light, first turn off the light. Slide down the access ring at the base of the head to uncover the USB-C port. Plug the USB-C connector into the USB-C port and plug the other end of the cord into a power source. LED charge indicators are located on the battery adjacent to the USB-C plug.

Battery LED Charge Indicators

- Charging...Red LED is on.
- Charged...Green LED is on.

Charge time is approximately 6 hours when using Streamlight AC adapters.

GENERAL OPERATION

Before first use, install and charge the battery. Remove the tailcap and insert the battery. Note that the tailcap thread will not engage unless the battery is properly orientated. Rotate the battery until it drops in place and reinstall the tailcap.

The ProTac® 2.0 series feature a programmable switch with momentary operation (light press or tap) and constant on operation (press until click).

- High: Tap and hold; click to lock on; click again for off.
- Strobe: Fast double-tap (within 0.4 seconds) and hold; click to lock on; click again for off.
- Low: Fast triple-tap (within 0.4 seconds per tap) and hold; click to lock on; click again for off.

Accessing Other Programs

The ProTac® 2.0 series feature a TEN-TAP® programmable switch allowing the user to select one of three different programs. To change to the next program, starting from the “Off” position, tap the switch rapidly 9 times (within 0.4 seconds per tap) and hold it down the 10th time. Continue holding the switch until the light turns off (approximately 1 second), then release the switch.

Available programs are High-Strobe-Low (Factory Default), High only or Low-Medium-High.

MAINTENANCE

Keep flashlight battery contacts clean at all times. Poor contact can cause malfunction. An abrasive pencil eraser works well to clean the contacts.

PRODUCT USE: Streamlight flashlights are intended for use as high intensity, heavy duty, and portable light sources. Use of Streamlight flashlights for any purpose other than as light sources is specifically discouraged by the manufacturer. Streamlight specifically disclaims liability for other than recommended use.

NOTICE Be sure to use only genuine Streamlight replacement parts to ensure product safety. Substitution may invalidate the product approval. Do not try to repair the unit yourself. Send to a qualified service facility or return it to the factory.

Streamlight Limited Lifetime Warranty

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. **THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.** You may have other specific legal rights which vary by jurisdiction.

Go to www.streamlight.com/support for a complete copy of the warranty. To register your product, go to www.streamlight.com (Online Product Registration). Retain your receipt or any proof of purchase.

SERVICE OPTIONS

The ProTac® 2.0 series contain few or no user-serviceable parts.

For service options, go to www.streamlight.com/support/service and complete the Online Service Request for factory service or to find the location of an authorized Streamlight repair center near you.

Or contact:

Customer Service

STREAMLIGHT, INC.

30 Eagleville Road

Suite 100

Eagleville, PA U.S.A. 19403-3996

Phone: (800) 523-7488 Toll-Free / +1 (610) 631-0600

Fax: (800) 220-7007 / +1 (610) 631-0712

997883 Rev. C 05/2025