


OPERATING INSTRUCTIONS FOR THE STREAMLIGHT PROTAC® HL-X & PROTAC® HP-X



IMPORTANT: FULLY CHARGE SL-B26® BATTERY PACK BEFORE FIRST USE.

Thank you for selecting the ProTac® HL-X or ProTac® HP-X tactical flashlight. As with any fine tool, reasonable care and maintenance of this product will provide years of dependable service. Please read this manual before using your ProTac®.

SAVE THESE INSTRUCTIONS. This guide contains important safety and operating instructions for your ProTac®.

⚠ WARNING  Fire and burn hazard. The ProTac® provides a powerful beam. When operated for more than a few seconds, it will get hot. Never leave your ProTac® with its face against any surface, including skin, while in operation. Transport or store the ProTac® in a way that minimizes the chance it can accidentally be turned on. The resultant heat build-up can cause a fire, burns or damage to the flashlight.

⚠ CAUTION STROBE MODE MAY CAUSE SEIZURES IN PERSONS WITH PHOTOSENSITIVE EPILEPSY.

LED SAFETY

⚠ CAUTION LED RADIATION (RG-2). DO NOT STARE INTO BEAM. MAY BE HARMFUL TO EYES. PER IEC 62471 Ed 1.0:2006-07.

BATTERY SAFETY

⚠ CAUTION EXPLOSION RISK, BURN, AND FIRE HAZARD. DO NOT DISASSEMBLE, CRUSH, SHORT CIRCUIT, HEAT ABOVE 140°F (60°C), OR DISCARD IN FIRE. DO NOT MIX CR123A BATTERIES OF DIFFERENT BRANDS OR OLD WITH NEW BATTERIES. DO NOT RECHARGE CR123A BATTERIES. ONLY USE STREAMLIGHT, PANASONIC, OR SANYO SIZE CR123A; DURACELL 123A, OR ENERGIZER 123. KEEP AWAY FROM CHILDREN. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

NOTICE This product is not designed to use rechargeable CR123A batteries.

The Streamlight SL-B26® battery is recyclable. At the end of its useful life, under various country and state laws, it may be illegal to dispose of this battery in the municipal solid waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal (In USA: RBRC).

BATTERY INSTALLATION/ REMOVAL

Uses one SL-B26® rechargeable battery or two CR123A batteries. Unscrew the tail cap and remove depleted battery(s), insert fresh battery(s) positive end first, replace and tighten tail cap.

SL-B26® USB BATTERY CHARGING

The ProTac® HL-X USB and ProTac® HP-X USB system ships with an SL-B26® battery with integrated charge port.

NOTICE Fully charge battery before first use.

To charge the SL-B26® battery, insert the USB-C plug into the connector near the positive end of the battery. The battery may be left plugged into the USB-C cable continuously, there is no danger of overcharging.

LED Charge Indicators

- Charging...Red LED is on.
- Charged...Green LED is on.

Charge time is approximately 5 hours when using Streamlight AC adapters.

GENERAL OPERATION

The ProTac® HL-X & ProTac® HP-X feature a programmable switch with momentary operation (light press or tap) and constant on operation (press until click).

- High: Tap and hold; click to lock on; click again for off.
- Strobe: Fast double-tap (within 0.4 seconds) and hold; click to lock on; click again for off.
- Low: Fast triple-tap (within 0.4 seconds per tap) and hold; click to lock on; click again for off.

Accessing Other Programs

The ProTac® HL-X & ProTac® HP-X feature a TEN-TAP® programmable switch allowing the user to select one of three different programs. To change to the next program, starting from the “Off” position, tap the switch rapidly 9 times (within 0.4 seconds per tap) and hold it down the 10th time. Continue holding the switch until the light turns off (approximately 1 second), then release the switch.

Available programs are High-Strobe-Low (Factory Default), High only or Low-Medium-High.

MAINTENANCE

It is important to keep the O-ring on the tail cap lubricated.

PRODUCT USE: Streamlight flashlights are intended for use as high intensity, heavy duty, and portable light sources. Use of Streamlight flashlights for any purpose other than as light sources is specifically discouraged by the manufacturer. Streamlight specifically disclaims liability for other than recommended use.

NOTICE Be sure to use only genuine Streamlight replacement parts to ensure product safety. Substitution may invalidate the product approval. Do not try to repair the unit yourself. Send to a qualified service facility or return it to the factory.

Streamlight Limited Lifetime Warranty

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. **THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.** You may have other specific legal rights which vary by jurisdiction.

Go to www.streamlight.com/support for a complete copy of the warranty. To register your product, go to www.streamlight.com (Online Product Registration). Retain your receipt or any proof of purchase.

SERVICE OPTIONS

The ProTac® HL-X & ProTac® HP-X contain few or no user-serviceable parts.

For service options, go to www.streamlight.com/support/service and complete the Online Service Request for factory service or to find the location of an authorized Streamlight repair center near you.

Or contact:

Customer Service
STREAMLIGHT, INC.
30 Eagleville Road
Suite 100
Eagleville, PA U.S.A. 19403-3996
Phone: (800) 523-7488 Toll-Free / +1 (610) 631-0600
Fax: (800) 220-7007 / +1 (610) 631-0712